

## Control of Work

## **BEFORE EACH JOB**

- Identify hazards and inspect the area. Ensure all team members know the status and conditions of the work area where they plan to perform work.
- Confirm whether Permit to Work and take time to exaluate the risks.
- In the corresponding Permits to Work, **measurements** of explosive atmosphere, carbon monoxide, carbon dioxide, nitrous oxide, hydrogen, methane, phosphine, oxygen, etc. will be made.
- While the task is being performed team members should:
  - Comply with the preventive measures of the permit, the specific procedures and the use of appropriate PPE.
  - Identify and communicate any hazard or potential uncontrolled risk situations to the supervisor.

## AFTER THE WORK

- Ensures that the area is in proper condition of **order and cleanliness**, with all protections placed and active.
- Report if there are any suggestions or opportunities for improvement.



Achieve a safe working environment through the Identification and evaluation of risks, definition of preventive measures and provision of Permit To Work.











